






LyteSwipe

Simple Freedom



LyteSwipe System Diagram



VisuLyte LyteSwipe is a multi-channel wireless mobile device App controller for up to 16 Lamps. Easy to operate music effects light show to create an entertaining performance. Just select colors and animations and Slide the Swipe to create new scenes continually keeping the DJ free to focus on the show. No PC, no programming, no setup* required.

SET-UP



APP Download– Download "RemoteXY Pro version App to your phone. Go to your phone settings, select connections and WiFi. With LyteSwipe powered look for "LyteSwipeXXX" network and connect using password "moodlyte". Open RemoteXY App then select + to add device network. Select "WiFi Point" connection and look for LyteSwipeXXX or <unknown network> and select. You may re-label the icon by press and hold of the icon button.

Pairing Lamps (Typically only need to perform one time)

- 1) Power On all Lamp Strips
- 2) Press and Hold **Setup** Button for 4 seconds till display shows "SETUP"
- 3) Press and Hold **Black** Button for 1 Seconds, Lamps center LEDs will flash Green
- 4) Tap **Beat On** button, Lamps all LEDs will turn Blue. Press again if not ALL Lamps Blue.
- 5) Touch each Lamp **Touch** button in sequence desired, Text display will verify Lamp # touch entry is received.
- 6) Tap **Beat Off** button to save Lamp sequence and exit SETUP Mode, Text display will verify number of Lamps Saved.
- 7) You may also Tap **Setup** Button to exit SETUP Mode.

OPERATION

Swipe Type Select - A-Center In/Out VU B-Center In/Out Static, C-Split all VU/Static D-Move VU/Static E-Move 1 VU, F-Move 1 Static

Swipe - Moves Lamps as Swipe Type selected

Animation Select - Select Static A or VU animations B-J

Animation Color - Slide select color of VU Animation only

Static Color - Select color of Static

Black - Toggles Off/On lamp brightness

Beat On– Enables Beat Enhanced VU animations

Beat Off– Disables Beat Enhanced VU animations

Noise Floor ADJ Pot - (Located on the Transceiver) Turn Pot to adjust Noise Floor. Noise Floor is the minimum level of audio pick up to reduce background noise when no music is present. Too high of setting may cause loss of full scale VU.



MoodLyte.com